

## FITTING INSTRUCTIONS TO BE FITTED BY A QUALIFIED TECHNICIAN



#### THIS SHEET INCLUDES FITTING INSTRUCTIONS FOR THE FOLLOWING PARTS:

Secondary Alternator Cover Part No. EC-V4S-SF-2020-1-GBR / Secondary Clutch Cover Part No. EC-V4-SF-2023-2-GBR Brake & Clutch Lever Guard Part No. BLG-14-A160-GBR / CLG-14-A160-GBR



### SECONDARY ALTERNATOR COVER PART NO. EC-V4S-SF-2020-1-GBR Bolt 1 Remove the 4 standard bolts as shown as bolt position 1, 2, 3 & 4. M6X30A2-TORX - 10Nm 1 2 Place the secondary alternator cover against the standard alternator. Insert the 4 supplied bolts and tighten to a maximum of 8Nm. 3 DO NOT OVERTIGHTEN Bolt 1 **GB**Racing® Racing Bolt 2 M6X30A2-TORX - 10Nm Bolt 3 0 Bolt 3 Bolt 4 M6X30A2-TORX -10Nm M6X35A2-TORX - 10Nm Bolt 2 Bolt 3 SECONDARY CLUTCH COVER PART NO. EC-V4-SF-2023-2-GBR M6X30A2-TORX -M6X30A2-TORX -10Nm (max) 10Nm (max) Remove 4 existing bolts from the Clutch cover, shown as position Bolt 1, 2, 3 & 4. 1 Place the Secondary Clutch Cover over the stock cover. 2 Assemble 4 replacement bolts loosely in the correct position as shown. 3 Tighten to a maximum Torque of 8Nm. DO NOT OVERTIGHTEN. 4 Bolt 1 M6X30A2-TORX - 10Nm (max) **GB**Racing® Bolt 4 M6X30A2-TORX - 10Nm (max) Bolt

ENGINE COVER SET: Part No. EC-V4-SF-2023-SET-GBR: EC-V4S-SF-2020-1-GBR, EC-V4-SF-2023-2-GBR




# FITTING INSTRUCTIONS



TO BE FITTED BY A QUALIFIED TECHNICIAN

## UNIVERSAL BRAKE LEVER GUARD WITH 14mm INSERT (Fits tube inside diameters from 13.6mm to 15.7mm)

- PART NO. BLG-14-A160-GBR
- 1 Remove existing bar end and replacing it with supplied bar end.
- 2 Tighten bolt until the lever protector is tight and does not move up or down under normal pressure.
- 3 Do not ride if you are unsure if it is tight enough and always get a trained technician to confirm.



### UNIVERSAL CLUTCH LEVER GUARD WITH 14mm INSERT (Fits tube inside diameters from 13.6mm to 15.7mm) PART NO. CLG-14-A160-GBR

- Remove existing bar end and replacing it with supplied bar end. 1
- 2 Tighten bolt until the lever protector is tight and does not move up or down under normal pressure.
- Do not ride if you are unsure if it is tight enough and always get a trained technician to confirm. 3

